



### **Included**

- 1. 3 - 1/4" x 1-1/4" fanged elevator bolts**
- 2. 3 - 5/16 wing nuts**
- 3. 3 - 1/4" fender washers**
- 4. Spout**

### **Instructions**

- 1. Place Re-direct spout kit over original spout**
- 2. Drill 3 - 5/16 holes through original spout using holes in Re-direct spout as template.**

